


▪ CURRENT PROBES

AmpFlex® Flexible AC Current Probe



ENGLISH

User Manual

 **AEMC**®
INSTRUMENTS
CHAUVIN ARNOUX GROUP

Find Quality Products Online at:

www.GlobalTestSupply.com

sales@GlobalTestSupply.com

Copyright © Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments. All rights reserved.

No part of this documentation may be reproduced in any form or by any means (including electronic storage and retrieval or translation into any other language) without prior agreement and written consent from Chauvin Arnoux®, Inc., as governed by United States and International copyright laws.

This documentation is provided “as is,” without warranty of any kind, express, implied, or otherwise. Chauvin Arnoux®, Inc. has made every reasonable effort to ensure that this documentation is accurate; but does not warrant the accuracy or completeness of the text, graphics, or other information contained in this documentation. Chauvin Arnoux®, Inc. shall not be liable for any damages, special, indirect, incidental, or inconsequential; including (but not limited to) physical, emotional or monetary damages due to lost revenues or lost profits that may result from the use of this documentation, whether or not the user of the documentation has been advised of the possibility of such damages.

Statement of Compliance

Chauvin Arnoux[®], Inc. d.b.a. AEMC[®] Instruments certifies that this instrument has been calibrated using standards and instruments traceable to international standards.

We guarantee that at the time of shipping your instrument has met its published specifications.

An NIST traceable certificate may be requested at the time of purchase, or obtained by returning the instrument to our repair and calibration facility, for a nominal charge.

The recommended calibration interval for this instrument is 12 months and begins on the date of receipt by the customer. For recalibration, please use our calibration services. Refer to our repair and calibration section at

Serial #: _____

Catalog #: _____

Model #: _____


Please fill in the appropriate date as indicated:

Date Received: _____

Date Calibration Due: _____



TABLE OF CONTENTS




1. INTRODUCTION	5
1.1 PRECAUTIONS FOR USE 	6
1.2 RECEIVING YOUR SHIPMENT	6
1.3 PACKAGING	6
2. PRODUCT FEATURES	7
2.1 DESCRIPTION	7
2.2 AMPFLEX®	8
2.3 FEATURES	9
2.4 ACCESSORIES	9
2.5 STANDARD MODELS	10
3. OPERATION	11
3.1 MAKING MEASUREMENTS WITH THE AMPFLEX®	11
3.2 TIPS FOR MAKING PRECISE MEASUREMENTS	11-14
3.3 TYPICAL RESPONSE CURVES	15-16
4. SPECIFICATIONS	17
4.1 COMMON SPECIFICATION	18
4.1.1 Electrical	18
4.1.2 Environmental Specifications	18
4.1.3 Mechanical Specifications	19
4.1.4 Sensor Specifications	19
4.1.5 Material Specifications	20
4.1.6 Safety Specifications	20
4.2 INSTRUMENT COMPATIBILITY	20
5. MAINTENANCE	21
5.1 BATTERY REPLACEMENT	21
5.2 CLEANING	21
5.3 REPAIR AND CALIBRATION	22
5.4 TECHNICAL AND SALES ASSISTANCE	22
5.5 LIMITED WARRANTY	23
5.6 WARRANTY REPAIRS	23

1. INTRODUCTION

Thank you for purchasing an AEMC® Instruments **AmpFlex® Flexible AC Current Probe**.

For best results from your instrument and for your safety, read the enclosed operating instructions carefully and comply with the precautions for use. These products must only be used by qualified and trained users.

Symbols

	This symbol signifies that the current probe is protected by double or reinforced insulation. Use only factory specified replacement parts when servicing the instrument.
	This symbol signifies CAUTION! and requests that the user refer to the user manual before using the instrument.
	This symbol refers to a type B current sensor. Do not apply around or remove from HAZARDOUS LIVE conductors without additional protective means (de-energizing the circuit or wearing protective clothing suitable for high voltage work).

Definition of Measurement Categories (CAT)

CAT IV corresponds to measurements taken at the source of low-voltage installations.

Example: power feeders, counters, and protections devices.

CAT III corresponds to measurements on building installations.

Example: distribution panel, circuit-breakers, machines, or fixed industrial devices.

CAT II corresponds to measurements taken on circuits directly connected to low-voltage installations.

Example: power supply to domestic electrical appliances and portable tools.

1.1 PRECAUTIONS FOR USE

These safety warnings are provided to ensure the safety of personnel and proper operation of the instrument.

- Read the instruction manual completely and follow all the safety information before attempting to use or service this instrument.
- Wear protective clothing and gloves as required.
- Use caution on any circuit: potentially high voltages and currents may be present and may pose a shock hazard.
- Read the safety specifications section prior to using the current probe. Never exceed the max voltage ratings given.
- Safety is the responsibility of the operator. The AmpFlex® must be used only by qualified personnel using applicable safety precautions.
- ALWAYS de-energize the circuit before wrapping the AmpFlex® around bare conductors, bus bars, or near live parts. Do not wrap on live conductors.
- ALWAYS connect the electronic module to the display device before wrapping the AmpFlex® around the sample being tested.
- ALWAYS inspect the module, sensor, sensor cable, and output terminals prior to use. Replace any defective parts immediately. Use only factory parts.
- NEVER use the AmpFlex® on electrical conductors rated above 600V CAT IV; 1000V CAT III.

1.2 RECEIVING YOUR SHIPMENT

Upon receiving your shipment, make sure that the contents are consistent with the packing list. Notify your distributor of any missing items. If the equipment appears to be damaged, file a claim immediately with the carrier and notify your distributor at once, giving a detailed description of any damage.

1.3 PACKAGING

Your AmpFlex® shipment consists of the following items:

- Flexible probe with electronic module.
- User manual.
- 9V battery.

2. PRODUCT FEATURES

2.1 DESCRIPTION

The AmpFlex® is a flexible AC current transformer composed of a flexible sensor and an electronic module. The flexible sensor permits measurements on conductors where standard clamp-on probes could not be used. In particular, it can be installed in tight spaces, around breaker panels, around cable bundles, around wide or large bus bars, or even wrapped around irregular shapes. The Shape Memory feature enables the user to “pre-shape” the sensor before inserting it between or around conductors. This feature facilitates closing, enhances user safety, and alleviates the drooping effect typically associated with flexible sensors.

The AmpFlex® is lightweight and does not use magnetic cores like standard transformers. The transformation principle is based on an air core. It presents virtually no load to the system under test, has a low phase shift, has excellent frequency response, and cannot be damaged by overloads.

The sensor assembly is waterproof and insulated for 600V CAT IV; 1000V CAT III. The AmpFlex® meets EN 61010-1, is CE marked, and is designed with materials and components to meet international agency standards.

The AmpFlex® has an mV output proportional to the current measured for direct readings on DMMs, data loggers, oscilloscopes, and power or harmonic meters. TRMS measurements are taken when connected to a TRMS meter. The AmpFlex® is insensitive to DC currents and only the AC component of the measured signal is measured.

The length of the flexible sensor can be selected in lengths of 24”, 36”, and 48” in length. Consult the factory for custom lengths, ranges and/or features.

2.2 AMPFLEX®




Figure 1

1.	Positive: Red Banana Plug (+).
2.	Common: Black Banana Plug (-).
3.	Power ON Indicator (Green LED).
4.	Overload Indicator (Red LED).
5.	Range Selection Switch.
6.	AmpFlex® Connector/Latch.
7.	Flexible Sensor (Diameter 0.5", 12.5mm).
8.	Lead from Sensor to Module (6.5ft, 2m).
9.	Electronic Module - Descriptive Label on Back Case (range, model, etc.)

2.3 FEATURES

- Models to measure from 0.5 ARMS to 30,000 ARMS.
- Accuracy: 1% of reading.
- TRMS measurements when connected to a TRMS instrument.
- No core saturation or damage if overloaded.
- Overrange LED for measurement circuitry.
- 600V CAT IV; 1000V CAT III; EN 61010; CE Mark.
- Waterproof sensor.
- 9V battery for typical 150 hour continuous operation.
- Shape Memory for custom pre-shaping of sensor before use (no drooping).
- Very high frequency response.
- Low phase shift for power.
- Insensitive to DC, measures only AC component on DC + AC signals.
- Excellent linearity.
- Lightweight.

2.4 ACCESSORIES

Banana (Female) / BNC (Male) Adapter.....**Cat. # 2118.46**

For connection of the AmpFlex® to SLII Models L101, L102, L562,
BNC terminals on scopes and other displaying instruments.

2.5 STANDARD MODELS

Model	Measurement Range	Output	Sensor Length	Max Conductor Size	Cat. #
300-24-2-10	30/300A	100/10mV/A	24" (610mm)	8" (190mm)	2112.88
1000-24-1-1	1000A	1mV/A	24" (610mm)	8" (190mm)	2112.39
1000-36-2-1	100/1000A	10/1mV/A	36" (910mm)	11" (290mm)	2113.00
3000-24-1-1	3000A	1mV/A	24" (610mm)	8" (190mm)	2112.46
3000-36-1-1	3000A	1mV/A	36" (910mm)	11" (290mm)	2112.48
3000-24-2-1	300/3000A	10/1mV/A	24" (610mm)	8" (190mm)	2113.05
3000-36-2-1	300/3000A	10/1mV/A	36" (910mm)	11" (290mm)	2112.00
3000-48-2-1	300/3000A	10/1mV/A	48" (1220mm)	15" (390mm)	2112.01
6000-36-2-0.1	600/6000A	1/0.1mV/A	36" (910mm)	11" (290mm)	2113.21
30000-24-2-0.1	3000/30,000A	1/0.1mV/A	24" (610mm)	8" (190mm)	2113.33

All AmpFlex® models are designed to be used with recorders or power analyzers with a voltage AC input. A scale factor may need to be entered into the recorder to display the exact value.

Custom lengths and ranges are available.

Contact us: customerservice@aemc.com

3. OPERATION

Please ensure that you have already read and fully understand the Precautions for Use section on page 6.

3.1 MAKING MEASUREMENTS WITH THE AMPFLEX®

- Connect the electronic module to the AC Volt range of your Digital Multi-Meter (DMM) or measuring instrument. Select the appropriate module output voltage range. If the current magnitude is unknown, and if AmpFlex® has two ranges, select the lowest mV/A output setting.
- Wrap the flexible core around the conductor to be tested. If possible within range, select the higher mV/A AmpFlex® output range to obtain the best resolution. Do not exceed specified current range for the output. Do not use on selected range if overload LED goes on.
- Read the displayed value on the DMM and divide it by the range selected (i.e. if reading = 2.59V with the 10mV/A output range, the current flowing through the probe is $2590\text{mV} \div 10 = 259\text{A}$).
- For best accuracy, carefully center the conductor inside the flexible core, and avoid if possible, the proximity of other conductors which may create noise and interference (particularly near the latch).
- True RMS measurements are obtained when the AmpFlex® is connected to a True RMS meter. Note that the DC component is not measured.

3.2 TIPS FOR MAKING PRECISE MEASUREMENTS

- When using the AmpFlex® with a meter, it is important to select the range that provides the best resolution. Failure to do this may result in measurement errors.
- For best results, select the highest AmpFlex® output signal possible and the most sensitive meter range for this output.
- Make sure the DMM or measuring instrument can accurately measure mVAC. Certain inexpensive DMM have poor resolution and accuracy when measuring low mVAC.
- For best accuracy, center the AmpFlex® around the conductor to be measured (see figure 2).

TIPS FOR MAKING PRECISE MEASUREMENTS (CONTINUED)

- To increase sensitivity or measure on low currents, the AmpFlex® may be wrapped several times around the conductor. **Divide your reading by the number of turns for the actual measurement (see Figure 4).**
- The overall measurement accuracy is the sum of the AmpFlex® accuracy and the displaying instrument accuracy.





Figure 2

TIPS FOR MAKING PRECISE MEASUREMENTS (CONTINUED)


- The AmpFlex® may be doubled around the conductor to be measured to double the output (see Figures 3 and 4 to show the different values on a DMM while measuring 250Aac).



One turn around a conductor carrying 250Aac.

Figure 3

TIPS FOR MAKING PRECISE MEASUREMENTS (CONTINUED)




Double the turns to double the output in low-current applications or for higher sensitivity.


Figure 4

3.3 TYPICAL RESPONSE CURVES


Typical Accuracy % vs. Frequency @ 100 A, 1 mV/A Output



Typical Accuracy % vs. Frequency @ 100 A, 10 mV/A




Typical Accuracy % per Range to 100 A




TYPICAL RESPONSE CURVES (CONTINUED)


Typical Phase Shift vs. Frequency @ 200 A, 1 mV/A Output



Current Derating Curve ($I < 3000$ A)



Current Derating Curve ($I > 3000$ A)



4. SPECIFICATIONS

Model	300A	30/300A	1000A	100/1000A
Measurement Range	5 to 300A	5 to 300A	5 to 1000A	5 to 1000A
Accuracy	±1% +200mA	±1% +200mA	±1% +200mA	±1% +200mA
Output Signal	10mV/A	100mV/A or 10mV/A	1mV/A	10mV/A or 1mV/A
Crest Factor (mid-range)	3.0	3.0	9.0	9.0
Phase Shift @ 50/60Hz	1.5°	1.3°	0.7°	0.7°
Residual Noise	200mA	200mA	200mA	200mA

Model	3000A	300/3000A	3000/30000A	600/6000A
Measurement Range	5 to 3000A	5 to 3000A	5-30000A	5 to 6000A
Accuracy	±1% +200mA	±1% +200mA	±1% +1A	±1% +500mA
Output Signal	1mV/A	10mV/A or 1mV/A	1mV/A or 0.1mV/A	1mV/A or 0.1mV/A
Crest Factor (mid-range)	3.0	3.0	3.0	> 10
Phase Shift @ 50/60Hz	0.7°	0.7°	0.5°	0.5°
Residual Noise	200mA	200mA	1A	500mA

***Reference Conditions:** 25°C ± 5°K, 20 to 75% RH, 1 minute warm-up, battery at 9V ± 0.5V, conductor center, external DC magnetic field < 40A/m, no external AC magnetic field, no external electrical field, 10 to 100Hz, sine wave. See accuracy curves for low currents.

4.1 COMMON SPECIFICATION

4.1.1 Electrical

Accuracy: 1% of reading \pm residual noise.

Frequency Range: 10 - 20,000Hz with current derating.

Signal Output: 4.5V max.

Working Voltage: 600V CAT IV; 1000V CAT III.

Frequency Influence:

See Accuracy vs. Frequency curves on pages 16 and 17.

Frequency Limitation:

See current derating curves (NOTE: no limitation on 300A Range) page 17.

Influence of adjacent conductor in contact with sensor and with AC signal:

0.2% typical, 2% maximum.

Influence of conductor position in sensor: 0.5% typical, 4% max.

Influence of shape of sensor: Oblong shape: 0.2% typical, 1% max.

Common Mode Rejection: 100dB typical, 80dB min.

4.1.2 Environmental Specifications

Operating Temperature Range: -14° to 131°F (-10° to +55°C).

Storage Temperature Range: -40° to 158°F (-40° to +70°C).

Influence of Temperature:

Sensor: 14° to 194°F (-10° to 90°C); 0.15% per 18°F (10°C) typical, 0.5% per 18°F 10°C max.

Module: 14° to 131°F (-10° to 55°C); 0.15% per 18°F (10°C) typical, 0.5% per 18°F (10°C) max.

Influence of Relative Humidity:

10 to 90% RH: 0.2% typical, 0.5% maximum.

Operating Relative Humidity:

50° to 86°F (10° to 30°C); 85° \pm 5% RH (without condensation).

104° to 122°F (40° to 50°C); 45° \pm 5% RH (without condensation).

Altitude:

Operating: 0 to 2000m, working voltage derating above.

Non-operating: 0 to 12,000m.

4.1.3 Mechanical Specifications

Module Output:

Two 4 mm safety banana jacks.
Standard 3/4" (19mm) spacing.

Battery: 9V Alkaline (NEDA 1604A, IEC 6LR61) recommended.

Battery Life: Useable from 9V to 7V, 150 hours typical (continuous use).

Low Battery: Power ON indicator (green LED) when battery voltage 7V, LED blinks when battery voltage is low.

Overload Indication: Red LED ON indicates the selected range is overloaded. Module output may not reflect the actual measurement.

Dimensions (sensor):

24", 36", and 48" nominal (± 1 "), other lengths optional.

Dimensions (Electronic Module): 4.9 x 2.5 x 1.1" (124 x 64 x 28mm).

Weight:

AmpFlex® 24" with battery: 0.74 lb.
AmpFlex® 36" with battery: 0.89 lb.
AmpFlex® 48" with battery: 0.95 lb.

Connection Cable Length (sensor to module): 6.5ft (2m).

Colors: Red sensor with dark gray connector and module, black connection cable (sensor to module).

Drop Test: Per IEC 68-2-32.

Vibration: Per IEC 68-2-6.

Mechanical Shock: Per IEC 68-2-27.

Weatherproofing: Module: IP40 (EN 60529).

4.1.4 Sensor Specifications

Weight: 10.8oz (302.4g).

Bend Radius: 0.75" (19mm) minimum.

Bending Life: >10000 without performance deterioration.

Waterproofing: IP 65.

Resistance to Chemicals: Resistant to oils and aliphatic hydrocarbons.

Diameter: 12mm \pm 0.5mm.

Outer Sheath Material: Polyurethane, UL94V0.

Dielectric Strength: 7500V.

Latch Spring Life: >10,000 maneuvers.

4.1.5 Material Specifications

Module: UL 94V2, Color dark gray, Polycarbonate.

Sensor Latch: Material: Lexan 500R, UL94V0.

Cable Assembly to Sensor: UL94V0, 1000V rating.

4.1.6 Safety Specifications



Electrical:

Double insulation or reinforced insulation between primary or secondary and outer case per EN 61010.

- 600V CAT IV; 1000V CAT III.

Pollution Degree 2.

- 7.50kV, 50/60Hz, dielectric between secondary and the outer case.

Electromagnetic Compatibility:

- Immunity: meets BF EN 61326-1 – Industrial environment category.
 - Electrostatic discharge (meets EN 61000-4-2).
 - 8kV in air – level 3 – class B.
 - 4kV on contact – level 2 – class B.
 - 10V/m radiated electromagnetic field (in line with EN 61000-4-3) – class B Rapid transients (in line with EN 61000-4-4).
 - 1kV – level 2 – class B.
 - Electric shocks (in line with EN 61000-4-5).
 - 6kV – class B.

4.2 INSTRUMENT COMPATIBILITY

The AmpFlex® is compatible with any multimeter, AC voltmeter, or other voltage measuring instrument with an input impedance greater than 1MΩ. To achieve the best overall accuracy, use the AmpFlex® with an AC voltmeter with an accuracy of 0.75% or better.

5. MAINTENANCE

Warning

- For maintenance use only specified replacement parts.
- To avoid electrical shock, do not attempt to perform any repair or service on the instrument unless you are qualified to do so.
- Do not perform any service while the AmpFlex® is on any circuit.
- To avoid electrical shock and/or damage to the instrument, do not get water or other foreign agents into the electronic module.
- Also see warning on page 2.

5.1 BATTERY REPLACEMENT

- If the power ON indicator (green LED) blinks or does not light up, replace the battery.
- Remove the AmpFlex® from any circuit before replacing the battery.
- To replace the battery, open rear case, replace battery, and reassemble. The green LED should go on when the module is turned on.

5.2 CLEANING

- It is important to keep the probe sensor latch mating surfaces clean and prevent foreign bodies from hampering the closing. The sensor may be gently cleaned with a soft cloth, soap and water. Dry immediately after cleaning. Avoid water penetration into the electronic module.
- Make sure the sensor, electronic module, and all leads are dry before any further use.

5.3 REPAIR AND CALIBRATION

To ensure that your instrument meets factory specifications, we recommend that it be submitted to our factory Service Center at one-year intervals for recalibration, or as required by other standards or internal procedures.

For instrument repair and calibration:

You must contact our Service Center for a Customer Service Authorization number (CSA#). This will ensure that when your instrument arrives, it will be tracked and processed promptly. Please write the CSA# on the outside of the shipping container. If the instrument is returned for calibration, we need to know if you want a standard calibration, or a calibration traceable to N.I.S.T. (includes calibration certificate plus recorded calibration data).

Ship to:

(Or contact your authorized distributor)

Costs for repair, standard calibration, and calibration traceable to N.I.S.T. are available.

NOTE: You must obtain a CSA# before returning any instrument.

5.4 TECHNICAL AND SALES ASSISTANCE

If you are experiencing any technical problems, or require any assistance with the proper operation or application of your instrument, please call, fax or e-mail our technical support hotline:

Contact: Chauvin Arnoux®, Inc. d.b.a. AEMC® Instruments
15 Faraday Drive
Dover, NH 03820 USA
Phone: (800) 343-1391 (Ext. 351)
Fax: (603) 742-2346
E-mail: techsupport@aemc.com

5.5 LIMITED WARRANTY

The instrument is warranted to the owner for a period of 2 years from the date of original purchase against defects in manufacture. This limited warranty is given by AEMC® Instruments, not by the distributor from whom it was purchased. This warranty is void if the unit has been tampered with, abused or if the defect is related to service not performed by AEMC® Instruments.

Please print the online Warranty Coverage Information for your records.

What AEMC® Instruments will do:

If a malfunction occurs within the warranty period, you may return the instrument to us for repair, provided we have your warranty registration information on file or a proof of purchase. AEMC® Instruments will repair or replace the faulty material at their discretion.

5.6 WARRANTY REPAIRS

What you must do to return an Instrument for Warranty Repair:

First, request a Customer Service Authorization Number (CSA#) by phone or by fax from our Service Department (see address below), then return the instrument along with the signed CSA Form. Please write the CSA# on the outside of the shipping container. Return the instrument, postage or shipment pre-paid to:

Caution: To protect yourself against in-transit loss, we recommend you insure your returned material.

NOTE: You must obtain a CSA# before returning any instrument.