



---

Large digit process indicator / controller  
**MAGNA 4 or 6-Digit Process**

**Installation & Operating Manual**


---



**Caution:** Risk of electrical shock if this instrument is not properly installed.



**Caution:** Read the whole manual before you install this display.



**Rear case screws - please note**

The rear panel is held in place with finger-screws, which only need to be gently tightened.

**Do not use tools to tighten or loosen the screws, as this could cause damage to the internal threads.**



**LAUREL Electronics, Inc.**

## Warranty

We warrant our products against defects in materials or workmanship for a period of one year from the date of purchase.

In the event of a defect during the warranty period, the unit should be returned, freight (and all duties and taxes) prepaid by the Buyer to the authorised distributor from where the unit was purchased.

The Distributor, at its option, will repair or replace the defective unit. The unit will be returned to the Buyer with freight charges prepaid by the distributor.

### LIMITATION OF WARRANTY

The foregoing warranty shall not apply to defects resulting from:

1. Improper or inadequate maintenance by the buyer.
2. Unauthorised modification or misuse.
3. Operation outside the environmental specification of the product.
4. Mishandling or abuse.

The warranty set forth above is exclusive and no other warranty, whether written or oral is expressed or implied. We specifically disclaim the implied warranties of merchantability and fitness for a particular purpose.

### EXCLUSIVE REMEDIES

The remedies provided herein are the buyer's sole and exclusive remedies.

In no event shall we be liable for direct, indirect, incidental or consequential damages (including loss of profits) whether based on contract, tort or any other legal theory.



# Contents

Warranty	2
Warnings	4
Introduction	5
General Description	6
Suspension Mounting Dimensions	7
Wall Mounting Dimensions	8
Panel Mounting Dimensions	9
Connections	10-11
Installation Hints for Best Performance	12-13
Language Selection for User Interface	14
Display Brightness	14
Display Calibration Modes	15
Direct Calibration - Full Scale Setting	16
Direct Calibration - Zero Setting	17
Linearization with Direct Calibration	18-19
Theoretical Cal - Decimal Point & Full Scale	20
Theoretical Cal - Low End Calibration	21
Linearization with Theoretical Cal	22-23
Sensor Drift correction	24
Logic Input functions	25
Logic Input Connections and Front Buttons	26
Factory Defaults	27
Calibration Audit Number	27
Signal Filtering / Averaging	28
Filter Jump Value	29
Last Digit Rounding Up by 1, 2, 5, 10, 20 or 50	30
Scale Factor Adjustment	31
Offset Adjustment	32
Menu Timeout Adjustment	33
Reverse Mirror Function (Mirror Image)	34
Bootup Routine and Tare Save Choices	35
Multi Memory Option MEM	36
Error Codes and Fault Finding	37
How to Install Option Boards	38
WEEE	39
Equipment Specifications	40
Record of Revisions	41
Input Board Filter Configuration	42
Declaration of CE Conformity	43

## Separate manuals for options

Alarm option settings	See Alarm manual *
Analogue output option settings	See Analog manual *
Serial output option settings	See Serial manual *
Real Time Clock setting	See Serial manual *

\* Need a manual urgently? Download manuals from our website.

# Warnings

Please carefully read this manual and all warnings. Install the display ONLY when you are sure that you've covered all aspects.



Where the product is intended for "UL" installations, removal or addition of option boards is not permitted.



Check that the model number and supply voltage suit your application before you install the display.



Connect the display according to current IEE regulations, IEC61010 & NFPA:70 National Electric Code in USA.



Power supplies to this equipment must have anti-surge (T) fuses rated at 1A for 230V supply, 2A for 110V supply, 5A for 48VAC supply or 10A for 11-30VDC.



Don't touch any circuitry after you have connected the display, because there may be lethal voltages on the circuit board.



Do not apply power to the display if its case is open.




Only adjust on-board switches or connections with the power turned off.



Make sure all screw terminals are tight before you switch the meter on.



Only clean the display's case and window with a soft damp cloth. Only lightly dampen with water. Do not use any other solvents.



## Rear case screws - please note

The rear panel is held in place with finger-screws, which only need to be gently tightened.

**Do not use tools to tighten or loosen the screws, as this could cause damage to the internal threads.**

# Introduction

Please contact us if you need help, if you have a complaint, or if you have suggestions to help us improve our products or services.

If you contact us about a product you already have, please tell us the full model number and serial number, so that we can give you accurate and fast help.

This product has a 3 year warranty. We will put right or replace any display which is faulty because of bad workmanship or materials. This warranty does not cover damage caused by misuse or accident.

If you return a unit for repair, please include a detailed description of the problem, and the name of a contact who we can refer to for any questions. Please mark for the attention of the QA Department.

## IMPORTANT

If this equipment is important to your process, you may want to buy a spare to cover possible failure or accidental damage in the future.

This is because during factory shutdown periods, you may have to wait several weeks for an equivalent replacement, or we may have no stock at the time you urgently need it.

You may also need to pay extra carriage charges if you want a fast, guaranteed courier service. Warranty repairs or replacements are usually returned with a standard courier service.

We do not offer compensation for losses caused by failure of this instrument.

If you do not agree with these conditions, please return this item in unused condition, in its original packaging and we will refund the purchase price, excluding any carriage paid.

We thought you'd prefer to know about possible delays and extra charges now, rather than during a panic. A spare unit could help to avoid these issues.

We always try to improve our products and services, so these may change over time. You should keep this manual safely, because future manuals, for new designs, may not describe this product accurately.

We believe these instructions are accurate, and that we have competently designed and manufactured the product, but please let us know if you find any errors.

## General Description

This series of displays accepts industrial sensors to allow various physical measurements to be made, such as weight, temperature, pressure, humidity etc. Different models are available for different sensor types.

The main function of this series is to give a clear numeric readout of the variable being monitored. Most models include an excitation power output, to power the sensor directly.

Various digit heights are available, to suit the maximum viewing distance required in each installation. For every 10 metres of viewing distance required, use 1" of digit height.

Various optional output modules are also available to give alarm relay outputs, analogue output or digital communications, or any combination of these options.

Displays are programmed using front panel pushbuttons. The front panel buttons can be disabled. In addition, you can connect 4 remote wired pushbuttons to the display, so that you can make adjustments while the display is mounted in an inaccessible location.

Power supply options: 100-240 VAC, 48VAC or 11-30VDC

These displays must be installed fully assembled, and must be installed according to local electrical installation rules.

When properly installed, and provided they have been ordered with cable glands exiting the lower surface of the case, they provide ingress protection to IP65 / NEMA4X from all directions.

### Safety



**Caution:** There is a risk of electrical shock if this display is not properly installed




**Caution:** Risk of danger: Read the whole manual before you install this display

Obey all safety warnings in this manual, and install the display according to local wiring and installation regulations. Failure to follow these guidelines may cause damage to the display, connected equipment, or may be harmful to personnel.


Any moving mechanical device controlled by this equipment must have suitable access guards to prevent injury to personnel if the display should fail.



# Suspension Mounting Dimensions



## Detail showing bracket hardware fitting sequence




You can order these displays with the cable glands in the bottom surface (as shown) the rear, or top. Rear glands allow you to mount the display on top of a cubicle, using the brackets shown.


**\* Do not use longer bolt threads than 12 mm, or you will fracture the female boss and the case will no longer be sealed.**

Display Format	X mm	H mm	W mm	Y mm
2" 4 digit clock	231	154.5	291	247
2" 4 digit numeric	219.5	154.5	279.5	249.5
2" 6 digit clock	340	154.5	400	370
2" 6 digit numeric	316	154.5	376	346
4" 4 digit clock	393	195.5	453	423
4" 4 digit numeric	374	195.5	434	404
4" 6 digit clock	593	195.5	653	623
4" 6 digit numeric	556	195.5	616	586
6" 4 digit	520	246	580	550
6" 6 digit	760	246	820	790
8" 4 digit	690	290	750	720
8" 6 digit	1012	290	1072	1042
12" 4 digit	990	408	1050	1020
12" 6 digit	1480	408	1540	1510
16" 4 digit	1308	515	1368	1338
16" 6 digit	1960	515	2020	1990

# Wall Mounting Dimensions



## Detail showing bracket hardware fitting sequence



You can order these displays with the cable glands in the bottom surface (as shown) the rear, or top. Rear glands allow you to mount the display on top of a cubicle, using the brackets shown.


**\* Do not use longer bolt threads than 12 mm , or you will fracture the female boss and the case will no longer be sealed.**

Display Format	X mm	H mm	W mm
2" 4 digit clock	278	154.5	291
2" 4 digit numeric	266.5	154.5	279.5
2" 6 digit clock	387	154.5	400
2" 6 digit numeric	363	154.5	376
4" 4 digit clock	440	195.5	453
4" 4 digit numeric	421	195.5	434
4" 6 digit clock	640	195.5	653
4" 6 digit numeric	603	195.5	616
6" 4 digit	567	246	580
6" 6 digit	807	246	820
8" 4 digit	737	290	750
8" 6 digit	1059	290	1072
12" 4 digit	1037	408	1050
12" 6 digit	1527	408	1540
16" 4 digit	1355	515	1368
16" 6 digit	2007	515	2020






# Panel Mounting Dimensions




## Detail showing bracket hardware fitting sequence

**Panel cutout dimensions**  
 $A+3\text{mm}(h) \times B+3\text{mm}(w)$




Display Format	H mm	A mm	B mm	Wmm
2" 4 digit clock	172.5	154.5	291	309
2" 4 digit numeric	172.5	154.5	279.5	297.5
2" 6 digit clock	172.5	154.5	400	418
2" 6 digit numeric	172.5	154.5	376	394
4" 4 digit clock	213.5	195.5	453	471
4" 4 digit numeric	213.5	195.5	434	452
4" 6 digit clock	213.5	195.5	653	671
4" 6 digit numeric	213.5	195.5	616	634
6" 4 digit	264	246	580	598
6" 6 digit	264	246	820	838
8" 4 digit	308	290	750	768
8" 6 digit	308	290	1072	1090
12" 4 digit	426	408	1050	1068
12" 6 digit	426	408	1540	1558
16" 4 digit	533	515	1368	1386
16" 6 digit	533	515	2020	2038

# Connections




**Warning:**  
Disconnect all power before removing the rear of the display

There is a wide range of possible locations for the input board, output board and power supply board/s. Their locations depend on the height of digits, number of digits, brightness of digits and any installed options. Because the permutation of possible locations is large, we will not describe the location of boards within the display, but simply identify the connectors and their functions on each board, below ...




- Connection Examples**
- A) 4-20mA direct, Term2 = -, Term3=+
  - B) 4-20mA 2 wire transmitter, link terminals 1&2, Term 3 = -, Term 6 =+
  - C) 0-10V direct, Term2 = -, Term4 = +
  - D) 3 wire potentiometer (if POT option ordered) link terminals 1 & 2 to low end of potentiometer, Term4 to wiper, Term6 to high end of pot.



# Connections



**Warning:**  
Disconnect all power before removing the rear of the display



## Remote programming button connector

On one of the display boards, you will find a 7 way connector, to which you can wire remote programming buttons, to allow adjustment of the display's settings when the display is inaccessible.

You can also enable or disable the display's front panel buttons, either by a remote contact closure, or by an on-board push-on jumper switch, which is located near to the remote button connector. When the contact is closed, or the push-on switch fitted, the front buttons are enabled.



## Rear case screws - please note

The rear panel is held in place with finger-screws, which only need to be gently tightened.


**Do not use tools to tighten or loosen the screws, as this could cause damage to the internal threads.**

# Installation Hints for Best Performance

This section offers several suggestions which will help you get the best performance from your measurement system.


Some sensors generate comparatively small signals which can easily be corrupted by the potentially high level of electrical noise which can be created by electrical machinery such as motors, welding systems, discharge lighting, AC power inverters and solenoids. These steps will ensure you get the best possible performance from your system.

1. Use good quality screened signal cable, with twisted pairs. Belden 8777NH, Belden 9503 and AlphaWire 6010C are good choices, available from many electrical distributors.
2. If you are using multi-pair twisted cable, each pair should be dedicated to a single display as shown opposite, for maximum noise immunity. This will ensure that any electrical noise induced in the cable is properly cancelled. Mixing destinations carelessly amongst the twisted pairs can actually worsen noise performance.
3. The cable should be routed away from noisy wiring and devices such as power feeds from inverters, discharge-lighting cables, welder cabling etc, and should preferably be routed in a dedicated low voltage signalling/instrumentation conduit or cable tray.
4. Screened cable should be earthed at the display end only.
5. All wires and screens coming out of the screened cable should be kept as short as possible to minimise pickup of noise.
6. If you are using barriers, you should earth your screen as shown below, paying particular care that you do not earth both ends of any run of of cable.



When using multi-core screened cable to connect several displays to several sensors, please be sure to use one twisted pair for each display and sensor.

Do NOT use a wire from one pair for signal positive and a wire from another pair for signal negative, as this will prevent the twisted cables from cancelling any induced electrical noise.



# Language Selection for User Interface

**1**

Press together, briefly

**Lockout Switch must be OFF**

Circuit board ON

**2**

Press to toggle

For 4 digits: **L E n 9** for English  
or **L F r A** for French.  
For 6 digits: **U I E n 9** for English  
or **U I F r A** for French.  
(Default = English)

**3**

Press to accept

**Done!**

# Display Brightness

You can adjust the display brightness at any time, provided the display is locked.

**1**

Press 3 seconds

**Lockout Switch must be ON**

Circuit board ON

**2**

Press for 3 seconds

For 4 digits, display shows **br 1**  
For 6 digits, display shows **br 9ht**  
Each press of the UP button selects a new brightness level. There are 7 brightness levels to choose from.  
(Default = Full brightness)

**3**

Press to accept

**Done!**

# Meter Calibration Modes

You can choose from two main calibration methods:

1. **Direct Calibration** - this is when you connect the meter to your system and make the meter read what you want it to, at two different points. *This is the preferred calibration method, because it allows you to calibrate the system as a whole.*
2. **Theoretical Calibration** - this is when you type in the sensor's theoretical signal level at the bottom and top of its range and then type in the value the display should show, for each signal level.

How to choose a calibration method:

**1** — **Lockout Switch must be OFF**   
 Press 3 seconds Circuit board **ON**

**2** —   
 Press to select dirECT or thEor For 4 digits, display shows **CAL** then **dir** or **thEor** (Default)  
For 6 digits, display shows **CAL Src** then **dirECT** or **thEor** (Default)

**3** —   
 Press to accept

If you chose Theoretical, you will now be asked whether your input signal will be DC Current or DC voltage ... the display will show **inP** (4 digits) or **inPut** (6 digits) followed by **dc A** or **dc U**

**4** —   
 Press to select dc A or dc V Display shows **inP** then **dc A** for current or **dc U** for voltage (Default)

**5** —   
 Press to accept  **Done!**



# Direct Calibration - Full Scale Setting


This is when you connect the meter to your system and make the meter read what you want it to, at 2 different points. *This is the preferred calibration method, because it allows you to calibrate the system as a whole.*


How to do direct calibration:-


If you have not done so before, please select Direct Calibration mode from the previous page.



First we recommend you set the **FULL SCALE** calibration ...

**1**  **Lockout Switch must be OFF**  
Display shows **0.00** (4 digits) or **0.0000** (6 digits) followed by **Set.H**  
Press 3 seconds 

**2**  Apply the highest calibration signal you can achieve, ideally 100% of system capacity. You can use less, but you will get better accuracy with higher signals. Now press OK

**3**  Press Set2 for 3 seconds. You can now set your decimal point position using the UP or DOWN buttons. Press OK when done.

**4**  You can now set the display value you want to see - use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value, as required.

**5**   Done!



# Direct Calibration - Zero Setting

How to calibrate the **ZERO** point.

**1** Press 3 seconds

Lockout Switch must be OFF

Circuit board ON

**2** Apply the lowest calibration signal you can achieve, ideally 0% of system capacity. Then press OK

For 4 digits, display shows **d r** followed by **Set.L**  
For 6 digits, display shows **d r Ect** followed by **Set Lo**

**3** You can now set the display value you want to see - use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value, as required.

**4** Press to accept

Done!

You can set Zero first, if you prefer, but you will not be able to change the decimal point position in the ZERO calibration step.

This will not be an issue if your zero calibration reading is 0, but may become confusing otherwise.

When you have finished your calibration, please remember to put the calibration lockout switch in its ON position, to protect your settings.

# Linearization with Direct Calibration

If your system is nonlinear, you can calibrate the meter and correct for this with the linearizer function.

You will need to apply a series of known loads, starting at 0 and working up to full scale. You will then tell the meter what it should read for each applied load. You can use up to 10 points.

First, you must select Direct Calibration Mode (see page on calibration Modes)  
Then, proceed as shown below...

**1** Press together, briefly

**Lockout Switch must be OFF** OFF

For 4 digits, display will show **L in.!** or **L in.0** (Default)  
For 6 digits, display will show **L in.0n** or **L in.OFF** (Default)

**2** If the display shows **L in.0** (4 digits) or **L in.OFF** (6 digits), press Set2 button briefly so that the display shows **L in.!** (4 digits) or **L in.0n** (6 digits), then press OK.

**3** The display will show **SE.00** (4 digits) or **SEt 00** (6 digits). Ensure that no load is applied to the system and press OK.

The display will now show **rd 00**. You can now tell the meter what it should display for this load.

Select each digit in turn with the DIGIT button, and increase or decrease each digit's value using the UP or DOWN button, until the display is set as required.

You can set the **Decimal Point** position by pressing the Set 2 button for 3 seconds. All decimal points will illuminate, but one will brighter than the others. Use the UP/DOWN buttons to choose a decimal point position and then press OK.

**4** The display will show **Ad.Pt** (4 digits) or **Add.Pt** (6 digits). Press OK.

Continued ...

# Linearization with Direct Calibration - cont'd.

5

Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

The display will show **SE.01** (4 digits) or **SEt 01** (6 digits). Apply your 1st known load to the system and press OK.

The display will now show **rd01** (4 or 6 digits). You can now tell the meter what it should display for this load.

Select each digit in turn with the DIGIT button, and increase or decrease each digit's value using the UP or DOWN button, until the display is set as required. Press OK when done.

6

Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

The display will show **rd.Pt** (4 digits) or **rd.Pt** (6 digits).

Press OK if you want to add another calibration point. You will repeat the previous steps, each time incrementing "Set XX" and "rd XX" up to Set 09 and rd 09, which are the last available points.

If you want to finish adding points, press Set2 until the display shows **SAVE**, and then confirm by pressing OK

If you want to abort the setup, press Set2 until the display shows **Quit** and then press OK

7


Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

**Done!**



# Theoretical Cal. - Decimal Point & Full Scale

This is when you type in the sensor's theoretical signal level at the top and bottom of its range and the value to display, for each signal level.



If you have not done so before, please select Theoretical Calibration mode from the **Meter Calibration** page AND choose whether your input is current or voltage.

First we recommend you set the **FULL SCALE** calibration ...

**1**

Press 3 seconds

**Lockout Switch must be OFF**

Circuit board ON

**2**

Display shows **thEo** (4 digits) or **thEoR** (6 digits) followed by **dC A** or **dC V**, depending on whether you have chosen current or voltage input, then **inH**.

**3**

You can now specify the maximum input signal. Use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value. Eg., set **20.00** (4 digits) or **20.0000** (6 digits) if your input is 4-20 mA.

Press to accept

**4**

Defaults are  
4-20mA = 0-100.0 for dCA and  
0-10V = 0-100.0 for dC V

Display now shows **rdH**, briefly. You can now specify the maximum reading and decimal point position. Press Set2 button for 3 seconds to set decimal point position. Use up and down arrows to move the decimal point and press OK when done. Then, use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value, as required. eg set 100.0 if your display range is 0 to 100.0

**5**






Press to accept

**Done!**





# Theoretical Calibration - Low End Calibration

This is when you type in the sensor's theoretical signal level at the top and bottom of its range and the value to display, for each signal level.





If you have not done so before, please select Theoretical Calibration mode from the **Meter Calibration** page.

**1** —     **Lockout Switch must be OFF**   
Circuit board ON





Press 3 seconds





**2** —     Display shows **Lo** (4 digits) or **Lo** (6 digits) followed by **dC A** or **dC U**, depending on whether you have chosen current or voltage input, then **in Lo**

Press OK. You can now specify the lowest input signal. Use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value, as required. Eg., set **04.00** (4 digits) or **04.0000** (6 digits) if your input is 4-20 mA.


**3** —    

Press to accept

**4** —     Display now shows **rd Lo** briefly. You can now specify the low reading. Use DIGIT to select each digit in turn, and the UP or DOWN arrow to increase or decrease each digit's value, as required. Eg., set **000.0** (4 digits) or **000.000** (6 digits) for 0 to 100.0 or 0 to 100.000

**5** —    

Press to accept

 **Done!**

You can set Zero first, if you prefer, but you will not be able to change the decimal point position in the ZERO calibration step. This will not be an issue if your zero calibration reading is 0, but may become confusing otherwise.

# Linearization with Theoretical Cal.

If your system is non linear, you can calibrate the meter and correct for this with the lineariser function.

With this method, you can enter theoretical values for input signal and display values, without having to connect a sensor.

First, you must select Theoretical Calibration Mode (see page on calibration Modes)  
Then, proceed as shown below...

**1** — **Lockout Switch must be OFF** OFF  
Press together, briefly  
Display will show **L in.1** or **L in.0** (4 digits), or **L in.0n** or **L in.OFF** (6 digits)

**2** — If the display shows **L in.0** or **L in.OFF**, press Set2 button briefly so that the display shows **L in.1** or **L in.0n**, then press OK.

**3** — The display will show **in 00** followed by an editing screen. Here you can enter your first calibration input signal level using DIGIT button to select each digit in turn. Increase or decrease the value of each digit using the UP or DOWN buttons. Press OK when set.  
  
The display will now show **rd 00**. You can now tell the meter what it should display for this input signal.  
  
Select each digit in turn with the DIGIT button, and increase or decrease each digit's value using the UP or DOWN button, until the display is set as required. Press OK when done.

**4** — Display will show **Ad.Pt** (4 digits) or **Ad.Pt** (6 digits). Press OK.

Continued ...



# Linearization with Theoretical Cal. - cont'd.

5

Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

The display will show **In 01** followed by an editing screen. Here you can enter your next calibration input signal level using DIGIT button to select each digit in turn. Increase or decrease the value of each digit using the UP or DOWN buttons. Press OK when set.

The display will now show **rd 01**. You can now tell the meter what it should display for this input signal.

Select each digit in turn with the DIGIT button, and increase or decrease each digit's value using the UP or DOWN button, until the display is set as required. Press OK when done.

6

Set1  
Digit

Set2  
In Lin

Output  
Reset

Alarms  
OK


The display will show **rd.Pt** (4 digits) or **rd.Pt** (6 digits).

Press OK if you want to add another calibration point. You will repeat the previous steps, each time incrementing **In XX** and **rd XX** up to In 09 and rd 09, which are the last available points.

If you want to finish adding points, press Set2 until the display shows **SAVE**, and then confirm by pressing OK.

If you want to abort the setup, press Set2 until the display shows **Quit** and then press OK.

**Done!**



# Sensor Drift Correction

If your system is normally reading 0, for example as is typical with platform scales or a torque meter, you may find a small amount of sensor drift caused by changes in temperature, ageing etc.

We can automatically correct for slow, long term drift, by comparing your signal to 0 every 30 seconds, and re-calibrating to remove any detected movement.

This does not affect the sensitivity of your system, and is only applied for readings less than 8 least-significant counts.

The corrected value is stored in non-volatile memory, so that any drift trend will be re-applied after you have switched off the meter.

**1** Lockout Switch must be OFF

Press together, briefly

Circuit board ON

**2** Press OK button briefly and repeatedly until you see **drF.0** or **drF.1** displayed for 4 digits, or **dr Ft.0** or **dr Ft.1** for 6 digits.

**3** Press DOWN or UP button to toggle between **drF.0** or **drF.1** (4 digits), or **dr Ft.0** or **dr Ft.1** (6 digits).

Press briefly to toggle

**drF.0** or **dr Ft.0** = No Correction (Def.)  
**drF.1** or **dr Ft.1** = Correction is active

**4** Press to accept

Done!



# Logic Input Functions

The three contact closure inputs on the rear of the meter have default functions which are:-

- Contact closure 1 = Tare
- Contact closure 2 = Peak/Valley display
- Contact closure 3 = Reset

You can re-assign these to include HOLD, Net/Gross value display, memory page address 1, 2 or 4 (only if Multi-memory MEM option is installed).

1

Set1 Digit	Set2 Max/Min	Output Tare	Alarms OK
---------------	-----------------	----------------	--------------

Press 3 seconds

**Lockout Switch must be OFF**

OFF

Circuit board
ON

2

Set1 Digit	Set2 Max/Min	Output Reset	Alarms OK
---------------	-----------------	-----------------	--------------

Press repeatedly until you see **CC. 1**, followed by the existing function for Contact Closure 1.

After you have set **CC. 1**, you will get the prompt **CC. 2** to allow you to set Contact Closure 2 function and when you have set CC.2 you will get the prompt **CC. 3** to allow you to set Contact Closure 3 function

3

Set1 Digit	Set2 Max/Min	Output Reset	Alarms OK
---------------	-----------------	-----------------	--------------

Use UP or DOWN buttons to select from these available functions...

<p>Defaults are:-</p> <p><b>CC. 1 = TARE</b></p> <p><b>CC. 2 = PU</b></p> <p><b>CC. 3 = rSt</b></p>	<p><b>TARE</b> = Tare display to 0</p> <p><b>PU</b> = Peak/Valley toggle</p> <p><b>rSt</b> = Reset</p> <p><b>Hold</b> = Freeze display</p> <p><b>nt.Gr</b> = Net / Gross display (4 digits)</p> <p><b>nEt.Gr</b> = Net / Gross display (6 digits)</p> <p><b>PA. 1</b> = Page Address 1*</p> <p><b>PA. 2</b> = Page Address 2*</p> <p><b>PA. 4</b> = Page Address 4*</p>
---	---

4

Set1 Digit	Set2 Max/Min	Output Reset	Alarms OK
---------------	-----------------	-----------------	--------------

Press to accept

**Done!**

\* Only available if the Multi-memory MEM option is installed

25

Find Quality Products Online at:

[www.GlobalTestSupply.com](http://www.GlobalTestSupply.com)

[sales@GlobalTestSupply.com](mailto:sales@GlobalTestSupply.com)


# Logic Input Connections and Front Buttons

The previous page explained how to select the functions of the 3 logic inputs. You can connect remote contact closures or open NPN collectors to activate these logic inputs.

The logic input provides a 5V DC signal. When you connect this to common, a current of 1mA will flow. Because this is a small signal, we recommend you use switches with gold plated contacts, or self cleaning contacts, for best long term reliability.

The logic inputs are not galvanically isolated from the input signal.

The logic inputs are only activated when the lockout switch is ON






- TAre** = Tares display to 0. Often used in weighing systems to zero a display prior to making a measurement. Net weight is shown once tared. When a display has been tared the small LED above the Set1 button will be illuminated.
- PU** = Peak/Valley toggle. Allows you to view the maximum and minimum values which have been displayed since last reset. 0% LED illuminates when showing valley, 100% LED illuminates when showing peak.
- rSt** = Reset. This clears any tare, peak, valley, alarm latch.
- Hold** = Freezes the displayed value for as long as the Hold input is closed.
- nGr** = Toggles between Net and Gross values on the display (4 digits).
- nEt.Gro** = Toggles between Net and Gross values on the display (6 digits).
- PA.1 .. 4** = Page Addresses, if MEM option is installed.



# Factory Defaults

You can return the display to its factory default conditions whenever you wish. If you do so, you will permanently lose all your settings and will need to start from the beginning again.

The calibration Audit Counter will NOT be reset, there is no way provided to reset this value, as it is intended as a secure record to indicate whether changes have been made to the display since it was last calibrated..

**1** —  **Lockout Switch must be OFF**   
Press together for 3 seconds Circuit board **ON**



**2** —  For “Defaults No”, the display shows **DEF.n** (4 digits) or **DEF5.n** (6 digits).  
For “Default Yes” and to return to default conditions, press the DOWN button to change the display to **DEF.y** (4 digits) or **DEF5.y** (6 digits).

**3** —    
Press to accept

# Calibration Audit Number

Your display includes a non-resettable counter which increments each time you make a change to the display’s calibration. This is useful if you want to check whether a display has been altered since it was last calibrated.


The calibration audit number ranges from **CL01** to **CLFF** (4 digits) or **CAL01** to **CALFF** (6 digits), allowing up to 255 alterations to be recorded. Whenever you want to check the calibration audit number, press and hold the 2 outer buttons (Set1 + Alarms) for more than 3 seconds.


**1** —    
Press together for 3 seconds


# Signal Filtering / Averaging

You can adjust the filtering time constant to reduce the effect of noise or instability on your input signal. A larger FIL value will give a more stable display, but the response to signal changes will be slower.

Because your output options, such as analogue output, alarm relays and serial output are all derived from the displayed value, they will respond at the same rate as the filtered display.


**1** —  **Lockout Switch must be OFF**  
Press 3 seconds

**2** —  **Display shows **FIL.XX.X** where **XX.X** is the time constant in seconds. Use the UP or DOWN button to increase or decrease this value**  
(Default = **FIL.000**)  
Select, then press OK to accept

**3** —  **Done!**  
Press to accept

See also Filter Jump setting if your signal is particularly noisy and you cannot get sufficient smoothing with this filter.

This meter also includes an active filter for removing the effects of vibration. It is shipped with the filter enabled for maximum stability. You can move a push-on jumper switch to change the filter response to maximum speed if you wish. See below.



# Filter Jump Value


The Filter Jump value allows you to decide how the display will respond to a process step change. It does this by overriding the filtering, if the input signal moves by more than a chosen amount in one conversion. The Filter Jump default value is 10%.

This means that for noise amplitude which has a peak value of less than 10% of the input range, filtering will be applied. Any signal movement greater than 10% of the input range will cause the display to jump immediately to that value, without filtering. After that jump, normal filtering will be re-applied, provided signal movement thereafter is less than 10% per conversion.

## Guidance:


For noisy systems, increase the Filter Jump value up to a maximum of 99. Choose a value which gives a good compromise between filtering and response speed.

For reasonably clean signals, a Filter Jump value of around 10 or less will give a good compromise between filtering and response speed to step change inputs.


- 


1 — Lockout Switch must be OFF

Press 3 seconds

Circuit board ON OFF
- 

2 — For 4 digits, press repeatedly until you see **F.J.XX** where **XX** is the Filter Jump percentage. (Default = **F.J.09**)

For 6 digits, press repeatedly until you see **F.L.J.XX** where **XX** is the Filter Jump percentage. (Default = **F.L.J.09**)
- 

3 — You can set from **00** to **99**. Use the DIGIT and UP or DOWN button to increase or decrease this value.
- 



4 — Done!


Press repeatedly to accept and return to display


# Last Digit Rounding Up by 1, 2, 5, 10, 20 or 50



You can adjust the way the display rounds up, which is useful if you want to display a very large number, but do not want jitter on the last digit.

The display can be set to round up to the nearest 1 (no rounding) 2, 5, 10, 20 or 50

**1** —  **Lockout Switch must be OFF**   
Circuit board ON

**2** —  For 4 digits, press repeatedly until you see **L.d.X** where X is either 1,2,5,10,20 or 50, (Default = **L.d. 1**)  
For 6 digits, press repeatedly until you see **LSt X** where X is either 1,2,5,10,20 or 50. (Default = **LSt 1**)

**3** —  Press repeatedly to change the LST value to the one you want.

**4** —   **Done!**

# Scale Factor Adjustment

After you have calibrated your meter, you can use the SCALE feature to make fine adjustments to calibration, without affecting the calibration itself.

## Example

### Changing volume units of measure from litres to Imperial gallons

You could also use the SCALE to convert your readout from litres to imperial gallons, without affecting the calibration. Simply set SCALE = 0.220 and your meter which was calibrated in litres will now read in imperial gallons.

### Changing weight units of measure from kg to pounds

You could also use the SCALE to convert your readout from kg to pounds, without affecting the calibration. Simply set SCALE = 2.205 and your meter which was calibrated in kg will now read in pounds.

**1** — Lockout Switch must be OFF

Set1 Digit Set2 Max/Min Output Reset Alarms OK

Press 3 seconds

Circuit board ON

**2** — For 4 digits, press repeatedly until you see **SCALE**, followed by the existing scale factor. (Default = **00 1.0**)  
For 6 digits, press repeatedly until you see **SCALE**, followed by the existing scale factor. (Default = **00 1.000**)

Set1 Digit Set2 Max/Min Output Reset Alarms OK

**3** — Use DIGIT button to select each digit in turn, UP or DOWN buttons to increase or decrease each digit's value. Press OK when done.

Set1 Digit Set2 Max/Min Output Reset Alarms OK

**4** — Press to accept

Done!

You may want to adjust an offset value also, see separate OFFSET page for this feature.

# Offset Adjustment

After you have calibrated your meter, you can use the Offset feature to make fine additions or subtractions to the reading, without affecting the calibration itself.

For example if your weighing structure is altered after calibration and you want to subtract the effect of 37kg of extra metalwork which was welded to the hopper, you can easily do this by entering a value of -37 in the offset value.

**1** — Lockout Switch must be OFF

Press 3 seconds

Circuit board ON

**2** — Press repeatedly until you see **OF.St** (4 digits) or **OFFSt** (6 digits), followed by the existing offset value. (Default is **000.0** for 4 digits or **000.000** for 6 digits)

**3** — Use DIGIT button to select each digit in turn, UP or DOWN buttons to increase or decrease each digit's value. If you want to set a negative value, use DIGIT to select the left hand digit, and press the down button to go below 0 to activate the - sign. Press OK when done.

**4** — Press to accept

Done!

You may want to adjust a SCALE FACTOR value also, without affecting calibration. See the separate SCALE page for this feature.



# Menu Timeout Adjustment

The display has a default timeout of 60 seconds, to allow you sufficient time to refer to the manual between key operations.

You can make this period shorter, if you wish, once you become more familiar with the setup method.

**1** — **Lockout Switch must be OFF**   
 Press together, briefly

**2** — Press repeatedly until you see **dY. XX** (4 digits) or **dLAY. XX** (6 digits), where **XX** is the delay in seconds. Choices are:  
**dY. 10** or **dLAY. 10**  
**dY. 20** or **dLAY. 20**  
**dY. 30** or **dLAY. 30**  
**dY. 60** or **dLAY. 60** (default)

**3** — Press **DOWN** or **UP** button briefly and repeatedly to choose from **dY. 10** or **dY. 20** or **dY. 30** or **dY. 60** (4 digits) or **dLAY. 10** or **dLAY. 20** or **dLAY. 30** or **dLAY. 60** (6 digits)  
 Press briefly to toggle

**4** — **Done!**  
 Press to accept

# Reverse Display Function (Mirror Image)

If you need to be able to see a reflection of the display in a mirror or other reflective surface, for example in a simple heads-up system, or for drivers reversing into a bay, using mirrors only, you can set the display to show as a mirror image.

1


Set1  
Digit

Set2  
Max/Min

Output  
↓

Alarms  
OK

**Lockout Switch must be OFF**



Press together, briefly

Circuit board
OFF  
ON

---

2

Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

Press OK button briefly and repeatedly until you see:

rEU.0 (Default) or rEU.! (4 digits)

rEU.d0 (Default) or rEU.d! (6 digits)

---

3

Set1  
Digit

Set2  
Max/Min

Output  
↓

Alarms  
OK

Press DOWN or UP button briefly and repeatedly to choose from

rEU.0 or rEU.d0 (normal display) or

rEU.! or rEU.d! (mirror image display)

Press briefly to toggle

---

4


Set1  
Digit

Set2  
Max/Min

Output  
Reset

Alarms  
OK

Press to accept



**Done!**

rEU.d 0

Example of normal display format displaying the number 876543

rEU.d !

Example of Mirror Reverse display format displaying the number 876543

24

Find Quality Products Online at:

[www.GlobalTestSupply.com](http://www.GlobalTestSupply.com)

[sales@GlobalTestSupply.com](mailto:sales@GlobalTestSupply.com)

# Bootup Routine and Tare Save Choices

When you switch on your meter, it can be set to power up with 3 possible summary message combinations. The choices are:-

**bt 0** (4 digits) or **boot 0** (6 digits) = Segment test, followed by a full summary of software revision, calibration audit number, model number, installed options.

**bt 1** (4 digits) or **boot 1** (6 digits) = Segment test followed by model number (Default)

**bt 2** (4 digits) or **boot 2** (6 digits) = No summary, meter displays the measurement value immediately when power is applied.

**bt 3** (4 digits) or **boot 3** (6 digits) = All segments illuminate permanently, until a button is pressed.

**1** — Lockout Switch must be OFF  
Circuit board ON

**2** — Press OK button briefly and repeatedly until you see **bt 0**, **bt 1**, **bt 2** or **bt 3** displayed (4 digits), or **boot 0**, **boot 1**, **boot 2** or **boot 3** (6 digits).

**3** — Press DOWN or UP button briefly and repeatedly to choose from **bt 0** to **bt 3** (4 digits), or **boot 0** to **boot 3** (6 digits).

**4** — Press to accept

**5** — Press to accept

**Done!**



You can trigger the full summary message whenever you want, without having to power the meter off, by pressing and holding the 2 outer buttons (Set1 + Alarms) for more than 3 seconds.

25

# Multi-Program Memory Option MEM

The three contact closure inputs on the rear of the meter may be used to call up between 1 to 7 additional meter setup memories (pages), if the MEM option has been installed. This allows you to save up to 8 complete sets of independent calibrations, alarm settings, analogue output settings and serial comms settings.

First decide how many memory pages you want, as this will determine how many logic inputs you will need to use for the addressing. Logic inputs not required for Page Addressing can be used for other functions such as Tare, Reset, Display Hold, Peak/Valley display.

If you have used all 3 logic inputs for Page Addressing, you can still use the meter's front panel buttons to perform Tare, Reset and peak/Valley view.

**See "Contact Closure Input Functions" page for CC.1, CC.2, CC.3 and COP settings**


Total number of pages	Logic Inputs required for addressing
1	none, standard single page meter
2	1 Set CC.1 = PA.1
3 or 4	2 Set CC.1 = PA.1, Set CC.2 = PA.2
5 to 8	3 Set CC.1 = PA.1, Set CC.2 = PA.2, Set CC.3 = PA.4

1. Set lockout switches OFF, and set page address to 0 or unplug the logic connector.
2. Set the copy instruction to **COP. 1** in page address 0 ( found after you set CC3) .
3. Press all 4 buttons together, display shows **dEF. n**
4. Press the Up arrow to change display to **dEF. y** and press OK.
5. If you want all channels to share a common setting, eg calibration, do that setting now.
6. When you want to do separate settings for each channel, set COP.0

## Programming and recalling individual pages

Plug the logic input connector back in, if you removed it earlier. Select a page address using the switch combinations shown below, wired to the Logic Input connector ...

Page address 0	All logic inputs open
Page address 1	CC.1 closed to Common
Page address 2	CC.2 closed to Common
Page address 3	CC.1 and CC.2 closed to Common
Page address 4	CC.4 closed to Common
Page address 5	CC.1 and CC.3 closed to Common
Page address 6	CC.2 and CC.3 closed to Common
Page address 7	All logic inputs closed to Common



Perform the settings you require, according to the pages in this manual. Do this for all page addresses required. Then put the lockout switch in its ON position. Now, if you select a page address, the meter will briefly confirm the chosen page address on screen, and will then function according to the settings you programmed for that address.

Suitable BCD coded switches are available from many electrical supply stores. For example consider Kraus & Naimer part A540-600 E24 or Apem part number IRBC10N1248 or London Electronics part number SW2P-8W-BCD, which also provides separate 2 pole 8 way signal selection function.

# Error Codes and Fault Finding



1. Under Range. The meter is being asked to display a value which is more negative than its limit of -1999



2. Over Range. The meter is being asked to display a value which is higher than its limit of 9999

These fault codes could be displayed because the signal is too negative, too positive, or because there is a wiring error, or because the display's scaling has been adjusted to give excessive sensitivity, or because there is a fault in the display.

a. If you are connecting a 4-20 mA signal to the display, please measure the DC millivolt signal between terminals 2(-) and 3(+) Ideally, you will measure 132 mV at 4 mA and 660 mV at 20 mA.

If the voltage is much higher, there may be a problem with the 33 Ohm input shunt resistor.

You can verify this as follows...

Remove the input signal and power connectors to the meter, and measure the resistance between terminals 2 and 3. This should be 33 Ohms. If it is more than this, the resistor has probably been overloaded and burned by having a voltage connected across it. Please check your field wiring to ensure that no more than 30 mA or 1V can be applied to the current input terminals.



Sometimes excessive current can feed to the current input of the display if your 2-wire 4-20 mA transmitter is faulty or is wired incorrectly, because we rely on the transmitter to regulate the loop current between 4 and 20 mA. The excitation power supply for the loop may have a much higher capacity than 20 mA.

b. If the measurements above were satisfactory, the problem may be caused by the scaling being too sensitive.

If you are happy to do so, it is a simple matter to reset the display's scaling to the factory default conditions. Put the lockout switch off and press all 4 buttons together for around 3 seconds until the display shows "dEFS n". Then press the UP button once so the display shows "dEFS Y". Now press the OK button and the display will be reset to factory defaults.

If still no success, please return the display to us for the attention of our QA Manager, with a report of what you found, for repair.


# How to Install Option Boards



If you want to open your display to install or modify option boards, follow these steps...

- 1) Switch off power to the display and unplug all connectors.
- 2) Undo all the thumb screws on the rear case, store them safely and remove the back panel
- 3) Locate the main option board, which will be similar in appearance to the diagram below. If a main option board is absent, which will be the case if the display was ordered without any output options, then a main option board will need to be fitted.

The board assemblies will look like this...



The analogue output and RS232 or RS422 plug-in option boards are fixed to the main option board with white plastic pillars. You must apply a firm force when fitting or removing these options.

Always be careful to connect the pins to sockets accurately. When reassembling, make sure option boards are firmly fixed to the upper option board.

# Waste Electrical Electronic Equipment (WEEE)

In Europe, this equipment must be disposed of in accordance with European Parliamentary Directive 2002/96/EC

This directive encourages recycling and the reduction of waste materials in the environment.

This means it must be sent to an approved recycling plant if you want to dispose of it.

It must not be thrown away with general rubbish.



## WEEE Waste Recycling

If you are unable to dispose of this item locally, you may send it to us for recycling.

### Conditions:

1. We will only accept items of our manufacture.
2. You must pay for the transport of the goods to us.
3. We will only accept items if they include a signed declaration by an authorised person in your organisation, stating that :-
  - i. The item is safe to handle and has no contaminants which may be harmful to health.
  - ii. You wish us to dispose of or destroy the item(s)

# Equipment Specifications

<b>Case Material</b>	Heavy duty welded uPVC.
<b>Connectors</b>	Internal detachable Screw Terminal connectors accessed via compression glands.
<b>Environmental</b>	Storage Temperature range -20 to +70°C, non condensing. Operating temperature range 0 to 50C. Internal heater option available for use in conditions down to -25°C.
<b>Power</b>	100-240 VAC, 48 VAC, 45 to 60Hz or 11-30 VDC optional.
<b>Burden</b>	40VA maximum.
<b>Sealing</b>	IP65 all round (NEMA-4) provided the display is mounted vertically and that all cable glands and rear case-closure screws are properly secured.
<b>Input Signals (bipolar)</b>	0-10V, 0-5V, 1-5V, 0-10mA, 0-20mA, 4-20mA
<b>Input Resistance</b>	1 Megohm for voltage, 33 Ohms for current inputs
<b>Accuracy</b>	+/-0.05% of range
<b>Span tempco</b>	25 ppm/°C
<b>Zero Tempco</b>	30 ppm/°C
<b>24V Excitation voltage</b>	24 VDC nominal rated at 60mA
<b>10V Excitation voltage</b>	10 VDC nominal rated at 20mA
<b>Filtering / smoothing</b>	Selectable time constants of 0 to 25 seconds.
<b>A/D conversion</b>	Sigma-Delta 10 conversions per second, 50/60Hz rejection Resolution 1 in 400 000 max. over full range
<b>Display update rate</b>	10 readings per second.
<b>Display Range (max)</b>	-199999 to +199999, depending on available signal level.

## Plug-In Output Options

<b>Analog Output</b>	See analog output manual for details. Available from our website.
<b>Alarm Relay Output</b>	See alarm output manual for details. Available from our website.
<b>ASCII Data Output</b>	See Serial output manual for details. Available from our website.
<b>Calendar/Clock option</b>	See serial output manual for details. Available from our website.



# Record of Revisions

6 September 2010	Version F0.18 Software released. Manual format revised to improve clarity and segregate easy from advanced menu functions. Optional outputs now described in their own dedicated manuals. DIN Rail mounting option added. Cabling guidance added.
17 November 2010	Version F00.19 Software released. Intended for use with 9122-2470 input board, having switched capacitor input filter feature. Code will auto detect this board. If a previous version board is installed, the meter will skip switched capacitor filter section of menu.  The newly released 9122-2470 input board allows 5V,10V or 24V excitation.
26 November 2010	Version F00.20 Software released. Allows serial data output to derived from Net or Gross measurement on full featured FX-XN-P versions
2 February 2011	Version F00.21 software released. New bootup routine added for LED testing.
28 February 2011	Warranty increased to 3 years and terms added.
30 August 2011	Corrected Remote Programmer connection details.
30 July 2014	Version F00.23 software released and V4 input board with active filter described
21 January 2016	Mounting dimensions amended for flush case bosses

# Input Board Filter Configuration



The new input board now offers a sharp cutoff active filter which rejects all vibrations above 7 Hz. This is idea in applications where mixing or vibration is common.

For optimum rejection of noise, we recommend you set the Fil.J parameter to 99 and choose a value for FIL which offers adequate filtering. Too large a value for FIL will slow the response of the meter.

If you need fast response, Disable the 7Hz filter according to the jumper settings shown below.

## Default Input configuration switches

Open S6, S9, S10, S13, S14, S15, S16, S17, S<sub>test</sub>. Link S1,S2, S3, S4, S5, S12, S18, S19



## Excitation voltages

- 5V DC Link S12 and S13. Open S14 and S15
- 10V DC Link S12 and S15. Open S14 and S13
- \* 24V DC Link S12. Open S13, S14 and S15

## Excitation Ratiometry

- \* Non ratiometric. Link S1. Open S6 (default)

## Active 7Hz. Low pass filter

- \* Enable: Link S18, S19.
- Open S16, S17, S<sub>test</sub>
- Disable: Link S16, S17.
- Open S18, S19, S<sub>test</sub>

# Declaration of CE Conformity

Declaration Reference : INTUITIVE Mk2  
Issue Date : 30 April 2007  
Products Covered : INTUITIVE Mk2 series  
Title : DOC-INTUITIVE2

This is to confirm that the Product covered by this declaration has been designed and manufactured to meet the limits of the following EMC Standard :

**EN61326-1:1997**

and has been designed to meet the applicable sections of the following safety standards

**EN61010-1:2001**



## Conditions

The meters are permitted a worst case error of 1% of A/D range during electromagnetic disturbance, and must recover automatically when disturbance ceases without the need for human intervention, such as resetting, power-down etc.

The meters covered by this certificate must be installed in adherence to the following conditions:

Signal cabling shall be routed separately to power carrying cabling (includes relay output wiring)

All signal cabling shall be screened. The screen shall only be terminated to the power earth terminal at the meter end of the cable.

**Software version F00.23**

Revision:23 Dated: 21 Jan 2016