ELECTRICAL TOOLS



PH-60C SWIV PUNCH* KNOCKOUT **PUNCH HEAD**

The Swiv-L-Punch Head, compatible with the exclusive RIDGID® QuickChange System™, delivers unparalleled efficiency to contractors and electricians.









Featuring the RIDGID QuickChange System





BENEFITS

- Effortlessly punch up to 4" holes without burdensome ratcheting or pumping
- Compatible with knockout punch dies from RIDGID and other manufacturers
- · Head can be rotated to virtually any orientation to access tight spaces
- · Combine with other heads in the RIDGID QuickChange System to maximize efficiency and productivity on the job site

SPECIFICATIONS

- Capacity: Punches up to 4" holes in 12 gauge mild steel and 14 gauge stainless steel
- Interchangeable head is compatible with 6-ton RIDGID Electrical Tools featuring the RIDGID QuickChange System
- Punch head swivels 360° and rotates 360° in the RIDGID QuickChange System
- Approximate Punch Time: 5 seconds
- Weight: 4.6 lbs. (2.1 kg)
- · Available as stand-alone head or in a RE 6 Tool Kit

ACCESSORIES

52278 Swiv-L-Punch Head Accessory Kit • Includes 2 spacers, 2 draw bolts, and 1 thread adapter 52378 Step Drill Bit

52278 & 52378 come standard with RE 6 Kit #52093. #52113, #52118 and #52123



ORDERING INFORMATION

KITS*

CATALOG NO.	DESCRIPTION	NO. OF HEADS	CUT SC-60C	CRIMP 4P-6	PUNCH PH-60C
52093	RE 6 Cut, Crimp, & Punch Kit**	3	\checkmark	✓	✓
52098 52113 52118	RE 6 Cut & Crimp Kit** RE 6 Cut & Punch Kit** RE 6 Crimp & Punch Kit	2	- < <	✓ - ✓	-
52103 52108 52133 52123	RE 6 Crimp Only Kit RE 6 Cut Only Kit (Cu/Al Blades) RE 6 Cut Only Kit (ACSR Blades) RE 6 Punch Only Kit	1	-	- - -	- - - - \sqrt
52088	RE 6 Tool Only Kit (No Heads)	0	_	_	_

^{*}All Kits Include: RE 6 Electrical Tool, (2) 18V Advanced Lithium 2 batteries, battery charger and blow-molded case **Includes SC-60C Cutter Head with Copper/Aluminum Blades.

ACCESSORIES

CATALOG NO.	DESCRIPTION	WEI	GHT (kg)	
46818	RE 6 Electrical Tool Only	5.5	2.5	
52083	RE 6 Electrical Tool Case Only	11.3	5.1	
52283	4P-6 4PIN™ Dieless Crimp Head Only	5.8	2.6	
52078	Swiv-L-Punch Head Only	4.6	2.1	
52278	Swiv-L-Punch Head Accessory Kit	1.2	0.5	
52378	Step Drill Bit	0.1	0.1	
47918	SC-60C Cutter Head – Copper/Aluminum Wire Blades	4.7	2.1	
49408	SC-60C Cutter Head – ACSR Wire Blades	4.7	2.1	
47923	Replacement Blades for Copper/Aluminum Wire	0.5	0.2	
47928	Replacement Blades for ACSR Wire	0.5	0.2	_
44693	18V Advanced Lithium 2.0Ah Battery	1.0	0.5	-887 10
44698	18V Advanced Lithium 4.0Ah Battery	1.5	0.7	2-8
43458	Advanced Lithium Battery Charger	1.8	8.0	766
44798	Advanced Lithium Battery Charger Replacement Cord	0.3	0.1	900

RE 6 Electrical Tool, Attachments & Accessories





SC-60C Scissor Cutter Head

Cat. No.	Description
47918	SC-60C Cutter Head With Copper/Aluminum Blades
49408	SC-60C Cutter Head With ACSR Blades
47923	Replacement Blades for Copper/Aluminum Wire
47928	Replacement Blades for ACSR



4P-6 4PIN™ Dieless Crimp Head


Cat. No.	Description
52283	4P-6 4PIN Dieless Crimp Head Only




Knockout Punch Sets

Cat. No.	Description
23487	KOPD-52 Set with 1/2", 3/4", 1", 11/4", 11/2", 2" Punches, Dies and Case
	KOPD-254 Set with $2^1/2^{"}$, $3^{"}$, $3^1/2^{"}$, $4^{"}$ Punches and Dies and Case

How the RIDGID® QuickChange System™ Works




1. Select the appropriate interchangeable head for the job.



2. Pull back the collar and insert the head until you hear a click confirming the connection.



3. Complete the job–cut, crimp or bunch.



4. Remove the head by pulling the movable collar toward the base of the tool.