



50 ppm



100 ppm



200 ppm



400 ppm

## **QAC QR TEST STRIPS**

### **CODE 2951 • 100 STRIPS**

1. Immerse pad in solution and remove immediately.
2. Hold strip level for 5 seconds. Shake off excess water from pad. Compare pad to color chart above.

**NOTE:** Sample must be at room temperature (above 75°F).  
If testing Hyamine 1622, change dip time to 45 seconds in Step 1.  
Keep out of sunlight.  
Keep vial closed when not in use.

