


Insta-TEST[®]

Nitrate
Nitrato
Nitrate

25 Test Strips
Tiras Reactivas
Bandelettes d'Analyse



Dip pad into sample and immerse for 2 seconds. Remove strip with pad face up. **DO NOT SHAKE OFF EXCESS WATER.** In shade, hold pad level for 60 seconds and read the strip.

- Keep wet fingers out of the bottle.
- Close cap tightly after removing strip.
- Store in a cool, dry place.

Sumerja la tira en la muestra durante 2 segundos. Retírela con el lado coloreado hacia arriba. **NO SACUDA EL EXCESO DE AGUA.** Mantenga la tira horizontal a la sombra por 60 segundos y haga la lectura.

- No toque el envase con los dedos húmedos.
- Cierre bien el envase luego de sacar la tira.
- Guarde el envase en un lugar frío, seco y oscuro.

Immerger pour 2 secondes dans l'échantillon d'eau. Retirer la bande face vers le haut. **NE PAS SECQUER.** À l'ombre, garder le niveau de la bande pour 60 secondes et lire.

- N'ne pas introduire les doigts trempés dans la bouteille.
- Refermer le capuchon.
- Entreposer dans un endroit frais, sec et ombragé.

Code 3012-G
Made in
USA

