



DC MILLIAMP CLAMP LOGGER KEW 2510





- Measures 4 to 20 mA instrumentation and process signals without breaking the loop
- Memory function stores up to 192000 data useful for monitoring the signals over time and fault finding
- Transfer data to PC via Bluetooth

- Top class measurement 0.2% accuracy
- Ø6mm clamp jaw easy to use in tight places
- LED light for illuminating the measurement spot
- Analog output terminal to allow the connection to a recorder or a digital multimeter

KEW 2510 Specifications

| NEW 2510 Specification | 113 | |
|----------------------------------|--|--|
| DC mA | 20/100mA(Auto ranging) ±0.2%rdg±5dgt(0.00mA - 21.49mA) ±1.0%rdg±5dgt(21.0mA - 120.0mA) | |
| Conductor size | φ6mm max. | |
| Analog output | Recorder: DC1000mV against DC100mA | |
| Communication Interface | Bluetooth Ver2.1+EDR Class2 | |
| Applicable Standards | IEC 61010-1, Pollution degree 2 IEC 61010-2-032, IEC 61326-1(EMC) IEC 60529 IP40, EN50581(RoHS) | |
| Operating temperature & humidity | -10 - +50°C <85% | |
| Storage temperature & humidity | -20 - +60℃ <85% | |
| Power source | R6/LR6(AA) (1.5V) x4 (Alkaline LR6 is recommended.) External supply (AC adapter MODEL8320) | |
| Battery life | Approx. 50 hours continuous with alkaline batteries (with Backlight, LED light and Bluetooth feature OFF) | |
| Dimensions | 111(L)x61(W)x46(D)mm : Display unit 104(L)x33(W)x20(D)mm : Sensor 700mm : Sensor Cable | |
| Weight | Approx. 310g(including batteries) | |
| Accessories | 8320(AC adapter), KEW Windows for 2510(Software) 9096(Carrying case), LR6(AA)x4, Instruction manual Software installation manual | |
| Optional | 7256(Output cord) | |











Included Accessories

Optional Accessory





Selection Guide

| | 2500 | 2510 NEW |
|-------------------------------|------|----------|
| | | |
| DC A 20/100mA | ✓ | ✓ |
| Conductor size ϕ 6mm max | ✓ | ✓ |
| Analog output | ✓ | ✓ |
| Memory | | ✓ |
| Data transmission (Bluetooth) | | ✓ |
| Power: Battery | ✓ | ✓ |
| Power: External Supply | | ✓ |



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely Safety Warnings: for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquires or orders: